# Eberspächer Climate Control System <u>User Instructions</u>

This vehicle is equipped with a fully automatic climate controller that maintains the user selected interior temperature using a digital keypad. This system controls both the independent water heating and air conditioning functions of this vehicle.

## Economy Mode

The climate control system should normally be operated in an ECON mode by depressing the **AUTO** key followed by the  $\langle \! \! \ \! \! \rangle$  Key. This will turn off the compressor and the corresponding LED.

In this mode the controller maintains the temperature by controlling the hot water heating circuit only. Fuel savings and a possible increase in available engine power are possible in this operating mode.

## Switching the Auto System ON

The AUTO system is turned on by pressing the **AUTO** key. In automatic mode the system will monitor the temperature inside the vehicle, adjusting it as required to maintain the pre-selected temperature.

### Changing the selected Temperature

The temperature can be adjusted by depressing the  $\triangle$  or  $\bigtriangledown$  keys on the left side of the panel. The temperature is selectable between 18 and 30°C or can provide maximum heating (displays HI) or maximum cooling (displays LO).

## Adjusting the Blower Speeds

The blowers have three speeds and are normally controlled by the climate controller. They can be adjusted manually by depressing the right hand  $\triangle$  or  $\bigtriangledown$  keys. The current blower speed is displayed on the control panel and is indicated by the LO, MED or HI LED illuminating.

#### Checking the Outside Air Temperature

The outside air temperature can be displayed for six seconds by momentarily pressing the **F** key. In ambient temperatures lower than 4°C, the display panel will blink automatically providing the outside air temperature to warn of the possibility of ice.

#### Switching the System Off

The climate control system can be switched off by depressing the OFF key.

Control Panel overview;





Eberspächer (UK) Ltd Vehicle Air Conditioning & Refrigeration Division Headlands Business Park, Salisbury Road, Ringwood, Hampshire, BH24 3PB Tel: +44 (0) 1425 480151, Fax:+44 (0) 1425 482721 email: enquiries@eberspacher.com Website: www.eberspacher.com